


# EIKI-SL II



1. Supply arm
2. Supply arm lock button
3. Film gate
4. Inching knob
5. Lens
6. Anamorphic lens holder
7. Focus knob
8. Framing lever
9. Elevator knob
10. Function switch
11. Optical/Magnetic playback selector switch (SL-02/2 only)
12. P.A. microphone jack
13. Voice/music selector switch
14. Tone control
15. Amplifier ON & OFF and volume control
16. Lamp house cover screw
17. Lamp house cover
18. Take-up arm lock button
19. Take-up arm